# **SMR-275** (Grey)

# Acrylic Lacquer Primer Surfacer

# **TECHNICAL DATA**

# **DESCRIPTION:**

SMR-275 Acrylic Lacquer Primer Surfacer is a premium quality acrylic lacquer primer for use in automotive applications. It is formulated with the highest quality resins. Dries quickly and sands very easily.

# FEATURES:

- ► Very fast dry time; sand in approximately 30 minutes
- Excellent adhesion to cured finishes, body filler and sanded fiberglass
- Superior filling and sanding properties
- ► Simple 1:1 mix ratio
- **▶** Economical

# **PACKAGING:**

| Part Number | Description                          | Size   | Qty. Case |
|-------------|--------------------------------------|--------|-----------|
| SMR-275     | Acrylic Lacquer Primer Surfacer Grey | Gallon | 4         |

# **MIXING:**

| 1 Parts Acrylic Lacquer Primer Surfacer |  |  |
|---|--|--|
| 1 Part                                  | Compliant Reducer (See Local VOC Laws) |  |

#### REDUCER OPTIONS:

(These contain PCBTF which is banned in some areas. Check local laws) SMR-0065 Zero VOC Reducer slow

SMR-0075 Zero VOC Reducer medium

SMR-0085 Zero VOC Reducer fast

#### REDUCER OPTIONS:

(For use within areas that allow reducers with a PW-MIR VOC Content Limit (g 03/g VOC) of 1.50)

SMR-1065 Universal Reducer slow

SMR -1075 Universal Reducer medium

SMR -1085 Universal Reducer fast

#### **GUN SETUP**

|                           | Fluid Tip   | pţi       |
|---------------------------|-------------|-----------|
| HVLP Spray Gun            | 1.6 – 1.8mm | 8-10 psi  |
| Conventional Gravity Feed | 1.6 – 1.8mm | 40-45 psi |

# SURFACE PREPARATION:

Wash area with soap and warm water. Thoroughly clean area with Pre Clean.

Sand area according to body filler manufacturer's recommendations. Reclean with pre-cleaner.

For optimum adhesion and corrosion protection, bare metal surfaces should be coated with Self Etching Primer or Epoxy Primer before applying primer surfacer.

# **APPLICATION:**

Apply 2-3 full wet coats of SMR-275 Acrylic Lacquer Primer Surfacer using a good quality spray gun with a 1.6mm to 1.8mm tip. Allow a minimum of 5-10 minutes flash time between coats. Allow 30 minutes @ 70F (21C) air dry before sanding.

### **SANDING:**

Allow SMR-275 Acrylic Lacquer Primer Surfacer to thoroughly dry before sanding.

320-400 grit sealer 320-400 grit single-stage system 400-500 grit basecoat

VOC INFORMATION
Coating Category: Primer Surfacer

|                            |                       |                         |                      |            |              |           | Exempt    | Density | PW MIR |
|----------------------------|-----------------------|-------------------------|----------------------|------------|--------------|-----------|-----------|---------|--------|
|                            | Regulatory VOC        | Regulatory VOC          | Actual VOC           | Actual VOC | Volatile Wt. | Water Wt. | Compounds | g/l     | VOC    |
|                            | lbs/gal               | g/l                     | lbs/gal              | g/l        | %            | %         | %         |         |        |
| SMR-275                    | 4.65                  | 557                     | 3.26                 | 390        | 57.35        | 0         | 22.45     | 1115    |        |
| (These contain PCBTF wh    | ich is banned in som  | e areas. Check local la | nws)                 |            |              |           |           |         |        |
| SMR-0065                   | 0                     | 0                       | 0                    | 0          | 100          | 0         | 100       | 859     |        |
| SMR-0075                   | 0                     | 0                       | 0                    | 0          | 100          | 0         | 100       | 899     |        |
| SMR-0085                   | 0                     | 0                       | 0                    | 0          | 100          | 0         | 100       | 943     |        |
| (For use within areas that | allow reducers with a | PW-MIR VOC Conten       | t Limit (g 03/g VOC) | of 1.50)   |              |           |           |         |        |
| SMR-1065                   | 7.31                  | 876                     | 4.57                 | 548        | 100          | 0         | 35        | 842     | 1.29   |
| SMR-1075                   | 7.5                   | 899                     | 5.04                 | 604        | 100          | 0         | 30        | 862     | 1.34   |
| SMR-1085                   | 7.53                  | 903                     | 5.86                 | 702        | 100          | 0         | 20        | 877     | 1.38   |
| Mixed VOC (1:1)            |                       |                         |                      |            |              |           |           |         |        |
| SMR-275 w/SMR-0075         |                       | 557                     |                      |            |              |           |           |         |        |
| SMR-275 w/SMR-1075         |                       | 557                     |                      |            |              |           |           |         |        |

#### Health and Safety:

See Safety Data Sheet and labels for additional safety information and handling instructions.

- \* The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and SDS's of all components, since the mixture will have the hazards of all its parts.
- \* Improper handling and use, for example, poor spray technique, inadequate engineering controls and or lack of Personal Protective Equipment (PPE), may result in hazardous conditions or injury.
- $^{\star}\,$  Follow spray equipment manufacturer's instructions to prevent personal injury or fire.
- \* Provide adequate ventilation for health and fire hazard control.
- \* Follow company, product SDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- \* Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on SDS.
- Always observe all applicable precautions and follow good safety and hygiene practices.
- FOR PROFESSIONAL USE ONLY